




#82170R, 82170G, 82170B Purge Cloud Illuminator Kit

Thank you for choosing ZEX™ products; we are proud to be your manufacturer of choice. Please read this instruction sheet carefully before beginning installation, and also take a moment to review the included limited warranty information.

Warning: The wire leads that are attached to the purge light have a special current limiting resistor factory installed. **Do not remove this resistor in an attempt to increase the brightness of the LED. If this is done, the LED will burn out immediately due to current overload. The warranty for the purge light will be voided if the wires from the resistor to the purge light have been cut in any way.**



Installation Instructions:

1. Locate the positive (+) 12V DC wire going to the purge solenoid and attach the red tee connector to it.
2. Take the red wire that is included in the kit and crimp the red male terminal to the end of it.

3. Plug the red wire into the red tee connector and run the length of wire up to where the purge kit's discharge tube is located.
4. Take the black (-) wire that is included in the kit and crimp the ground ring to the end of it.
5. Locate a good chassis ground and attach the ground ring to this location. Run the black wire to where the purge kit's discharge tube is located.
6. Take the butt connectors and crimp the red (+) and black (-) wires to the color matching red and black wires that are attached to the purge light.
7. Slide the purge light over the end of your purge kit's discharge tube. Tighten the set-screw to lock the purge light onto the tube.
8. Press the purge kit button and verify that the light comes on.
9. Open the nitrous bottle valve, spray the purge kit, and enjoy the light show.

Limited Warranty

ZEX™ warrants that all of its products are free from defects in material and workmanship, and against excessive wear for a period of (1) one year from the date of purchase. This **limited warranty** shall cover the original purchaser.

ZEX's obligation under this warranty is limited to the repair or replacement of its product. To make a warranty claim, the part must be returned within (1) one year of purchase to the address listed below, freight prepaid. Items covered under warranty will be returned to you freight collect.

It is the responsibility of the installer to ensure that all of the components are correct before installation. We assume no liability for any errors made in tolerances, component selection, or installation.

There is absolutely no warranty on the following:

- A) **Any parts used in racing applications;**
- B) **Any product that has been physically altered, improperly installed or maintained;**
- C) **Any product used in improper applications, abused, or not used in conjunction with the proper parts.**

There are no implied warranties of merchantability or fitness for a particular purpose. There are no warranties, which extend beyond the description of the face hereof. ZEX™ will not be responsible for incidental and consequential damages, property damage or personal injury damages to the extent permitted by law. Where required by law, implied warranties or merchantability and fitness are limited for a term of (1) one year from the date of original purchase.

This warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.